



TP7144 • Master Equipment X-Tend Electric Grooming Table

- Lifts up to 200 lbs
- Height adjusts from 11" to 47 1/2"
- Durable, rust-resistant, electro-coated finish
- 43 1/2"L x 23 1/2"W x 1" thick tabletop
- Heavy-duty steel construction
- Dual foot pedals on base for easy raising and lower of table

SAVE THESE INSTRUCTIONS • IMPORTANT SAFEGUARDS

CAUTION:

Do not leave an animal on the table unattended. Use a grooming loop to properly restrain animal. Quick-release loops or clips are recommended to prevent injury in case animal accidentally jumps off the table. Do not use a choke-style lead or collar.

WARNING:

To reduce the risk of burns, fire, electrical shock, or injury to person or pets:

1. Do not leave grooming table plugged in when unattended.
2. Do not allow unsupervised children to play near or operate the table.
3. Do not immerse motor in water or other liquids.
4. Unplug table before cleaning or servicing.
5. Use table only for its intended use described in this manual. Do not use attachments not recommended by the manufacturer.
6. Never operate this grooming table if it has a damaged cord or plug, or if it is not working properly. If table is not working or is damaged, contact PetEdge customer service at 1-800-638-5754.
7. Keep cord away from heated surfaces.
8. Do not place or store this appliance where cord may be damaged by an animal or exposed to weather

CARE & MAINTENANCE:

Unplug table. Wipe off tabletop with a sponge or damp cloth and mild cleaner after use. Recommend using mild soap and water, or a on-caustic cleaner. Periodically vacuum or dry wipe, lifting mechanism to keep it free from hair and debris. Base can also be cleaned when needed with damp cloth or sponge. Dry off any excess water. Check electric cord and plug for signs of damage or wear.

OPERATING INSTRUCTIONS:

This table is designed for use with standard 120V outlet. This grooming table also has a polarized plug (one blade is wider than the other). As an important safety feature, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the the proper outlet. Do not attempt to modify the plug in any way. This table is also designed with an automatic shut-off. Motor, transformer, and cord are all UL approved. We recommend that this table be used with a surge protector at all times.

ASSEMBLY OF FOLDABLE GROOMING ARM:

1. Place arm support base on edge of grooming table and and tighten bolt clamp to secure to tabletop.
2. Loosen height adjustment knobs and slide grooming arm post at both top and bottom until it is at desired height. Tighten knobs to lock into place.
3. Swing foldable arm over post until it is positioned over table perpendicular to grooming post.
4. Attach grooming loop to eye-screw at top of arm.
5. Fold arm back against post when not in use.

OPERATING TABLE:

1. Table is fully assembled. Before use, make sure table is level by turning leveling feet under each base leg. Plug cord into any standard 110/120V wall outlet.
2. This grooming table is equipped with identical up and down control pedals located on each side of the table base. The pedal on your right as you are facing the table moves the table up; the pedal on your left moves the table down.
3. To reduce strain and unnecessary lifting of heavy animals, it is recommended to lower the table to the minimum height and let animal step up onto the table before positioning table to desired height for grooming.
4. Once animal is positioned on table, place the grooming loop that is attached to grooming arm around animal's neck and adjust to fit comfortably.



TROUBLESHOOTING:

In rare cases, some electrical connections may be jostled loose during shipment. If controls do not operate once the table is plugged in, please read the following steps for either checking and reconnecting a loose wire in the control box or replacing the transmission shaft.

Problem: Table Does Not Turn On

Possible Causes: Table Not Plugged In, Control Box Connection Loose, Transformer Defective

1. Check that the table is plugged in to a working outlet.
2. Check the connections in Control Box.

To Check Control Box

1. Unplug table and turn it on its side so that black wire cover panel on side of frame is facing top and easily accessible. Using a Philips-head screwdriver, unscrew the six screws along the side of the bottom panel of the Control Box to uncover transformer.
2. Make sure both of the "M" plugs (black wires) are securely fastened to the transformer socket.
3. Ensure all plug connections for the foot pedals (black plug) are securely fastened.
4. Check transformer for damage. If damaged, unscrew two screws on top of the Control Box and remove metal frame around Transformer.
5. To replace Transformer, unplug connections, slide metal frame around the new Transformer and insert into the Control Box. Screw into place and secure.
6. Reattach back panel onto the Control Box and screw into place.

Problem: Table does not raise or lower after table is turned on.

Possible Causes: Transmission Cable of Shaft may be defective.

To check Transmission Cable:

1. Unscrew black protective cover from the wire connecting the Transmission Shaft to the Control Box (located alongside of table base).
2. Inspect wire for any damage.
3. Leave protective cover off until you finish checking Transmission Shaft.

To Replace Transmission Shaft:

1. Using a wrench, loosen and remove the small bolt holding the Transmission Shaft to the bottom of the table base.
2. Loosen and remove the large bolt holding the Transmission Shaft to the top of the table base.
3. Using either an allen wrench on the bolt end or an open-end wrench on the nut, loosen and remove the bolt to disconnect end of Transmission Shaft.
4. Disconnect plug ends from Transformer socket.
5. Remove Transformer shaft.
6. Slide new Transmission shaft into place and reattach bolts. Note: Fasteners on end should have longer fastener on bottom and shorter on top to correctly position shaft.
7. Attach cable plugs into Transformer socket.
8. Snap plastic guard over wire and insert in slot in side of Control Box. Exposed wire should be snug to box.
9. Attach cable plugs into Transformer socket and place excess wire in Control Box.
10. Reattach bottom panel on Control Box and screw into place to secure.

LIMITED WARRANTY

This Master Equipment® X-Tend Electric Grooming Table is warranted against defective material or workmanship for one year from the date of purchase. Any Master Equipment® product that is determined to be defective in material or workmanship during the warranty period will be replaced without cost to the purchaser for parts or labor. Please contact Boss Pet Products Customer Service at 1-800-638-5754 regarding any defective product. Boss Pet Products will not be liable under this warranty for any defect, failure or malfunction of this product caused by normal wear, abuse, misuse, unauthorized adjustments or repairs. Boss Pet Products will not be liable for any incidental or consequential damages of any type. Any implied warranty is limited to the one-year period provided in this express warranty. Some states do not allow limitations on how long an implied warranty lasts or exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. Warranty is void if product has been modified in any manner, repaired by anyone other than Boss Pet Products or has been subject to unreasonable use. Warranty is valid in the United States.

Date Purchase: _____



Manufactured for

© Boss Pet Products, Inc., Danvers, MA 01923
MADE IN CHINA

TP7144 Master Equipment
X-Tend Electric Grooming Table